

HDJ-CUE1BT-K / HDJ-CUE1BT-W / HDJ-CUE1BT-R

DJ Headphones with *Bluetooth*® functionality Casque DJ avec fonction *Bluetooth*® DJ-Kopfhörer mit *Bluetooth*®-Funktion Cuffie per DJ con funzionalità *Bluetooth*® DJ-koptelefoon met *Bluetooth*®-functie Auriculares para DJ con funcionalidad *Bluetooth*® Headphones DJ com funcionalidade *Bluetooth*® Hayшники для ди-джеев с поддержкой *Bluetooth*® 带蓝牙®功能的DJ耳机有*Bluetooth*®功能的DJ耳機
Bluetooth®機能搭載DJヘッドホン

Instruction manual
Mode d'emploi
Bedienungsanleitung
Manuale di istruzioni
Gebruikershandleiding
Manual de instrucciones
Manual de instruções
Инструкция по эксплуатации
使用说明书
操作手冊
取扱説明書

保留备用 使用产品前请阅读使用说明

pioneerdj.com/support/

For FAQs and other support information for this product, visit the above site.

Pour les FAQ et autres informations de support sur ce produit, consultez le site ci-dessus.

Häufig gestellte Fragen und weitere Support-Informationen für dieses Produkt finden Sie auf der oben genannten Seite.

Per la sezione FAQ e altre informazioni di supporto per questo prodotto, visitare il sito indicato sopra.

Bezoek de bovenstaande website voor vaak gestelde vragen en andere informatie over ondersteuning voor dit product. Para consultar las preguntas más frecuentes y otras informaciones de asistencia para este producto, visite el sitio indicado

Para obter informações sobre as FAQs e outras informações de apoio relativas a este produto, consulte o site indicado acima.

Ответы на часто задаваемые вопросы и другую дополнительную информацию о данном изделии см. на указанном выше сайте.

关于此产品的常见问题和其他支持信息,请访问以上网站。

如需本產品的FAQ與其他支援資訊,請造訪以上網站。

上記のサイトで、本製品のFAQなどのサポート情報をご覧いただけます。




AlphaTheta Corporation

6F, Yokohama i-Mark Place, 4-4-5 Minatomirai, Nishi-ku, Yokohama, Kanagawa 220-0012 JAPAN / JAPON

AlphaTheta株式会社

〒220-0012 神奈川県横浜市西区みなとみらい4丁目4番5号 横浜アイマークプレイス6階

Part names



1. Volume buttons

2. **LED**

Blinks specific sequences and colors to provide notification of device status.

3. Multifunction button

Power (switches the device off and on)

Pairing

Play/Pause/Rewind/Forward

Call

4. Coiled cable connector

Connect the supplied coiled cable.

5. Charging terminal

Connect the supplied USB charging cable to charge.

6. Microphone


· Product illustrations may differ from the actual product.

How to charge the headphones

After purchasing, please charge before use.

1 Connect the headphones to a PC/Mac with the supplied USB charging cable.

- · The red LED lights.
- The red LED lights while charging and turns off when charging is complete.
- Fully charging from an empty state takes approximately 2.5 hours.



Notes

- During charging, Bluetooth devices cannot be connected.
- The recommended charging temperature range is 10°C to 35°C.
- If a connection is established while the power is on, the power turns off automatically.
- The headphones cannot be turned on during charging.
- Do not use any cable other than the supplied USB charging cable.
- The headphones may not be charged in some cases when the PC/Mac is in standby or sleep modes.

Cautions regarding the USB charging cable

- Do not use connectors on which the terminal section has been twisted.
- When connecting the connector, check the connection direction and insert it directly.
- Do not allow fluids (sweat or drinking water) or foreign matter (small items of refuse or dust, metal, etc.) to adhere to the connector section.

T	Turning the power on/off						
Tı	urning	the p	oower on				
1	Press secon		multifunction	button	for	approximately	three
Tı	urning	the p	oower off				
1	Droop	46.0		btton	£a.	annrovimatoly	1 b.v.o.o.

seconds while the power is on.

Connecting via Bluetooth

Preparations


- Bring the Bluetooth device within approximately 1 m of the headphones
- If necessary, read the user's manual of the device that you are trying to connect in order to confirm how to use it

Pair (register) the headphones with the *Bluetooth* device and connect them

1 With the power turned off, press and hold the multifunction button on the headphones until the LED blinks.

When connecting a device for the first time: Approx. 3 seconds When connecting the second or subsequent device: Approx. 5 seconds

- The headphones begin searching for the Bluetooth device to connect to, and the LED blinks red and white alternately.
- 2 Turn on the Bluetooth device and activate it.
- 3 From the *Bluetooth* menu on the *Bluetooth* device, select the device name "HDJ-CUE1BT".



- In some cases the MAC address "□□□□□□" (where "□" is a specific character string that differs for each device) appears before "HDJ-CUE1BT" is displayed.
- If a passkey entry is requested, enter the passkey of the headphones "0000" (four zeros).

4 On the headphones, check the connection to the paired *Bluetooth* device.

- The LED blinks red and white alternately until connection with the device is complete.
- When the white LED lights, pairing is complete.

- The headphones power will turn off if connection to the device does not complete within five minutes. If this occurs, register the device again.
- Two or more *Bluetooth* devices cannot be connected with the headphones at the same time.
- The headphones can register up to eight *Bluetooth* devices. If more than the maximum number of devices are registered, already registered *Bluetooth* devices will be overwritten in order from the device first connected. Register the devices again if you wish to use them.
- If the headphones are near to a *Bluetooth* device that it was previously connected to, it may automatically connect to the same device upon turning on. To connect to a different *Bluetooth* device, turn off the *Bluetooth* function of the connected *Bluetooth* device or turn off the headphones and carry out pairing again.

Listening to music

Listening to music with Bluetooth

If the *Bluetooth* device is compatible with "A2DP" or "AVRCP" *Bluetooth* profiles, you can use the remote control on the headphones to perform actions such as music playback.


- A2DP (Advanced Audio Distribution Profile): Transfers sound to the headphones.
- AVRCP (Audio/Video Remote Control Profile): Allows remote control operation from the headphones.
- 1 Connect the *Bluetooth* device to the headphones (page 5).
- 2 Choose the music or video you wish to listen to from the Bluetooth device.
 - The sound from the music or video plays back through the headphones.
 - When fully charged, playback time is approximately 30 hours. (Sometimes less depending on the conditions of use.)

- · Note that the sound may leak out of the headphones at certain volume levels.
- Increasing the volume of the headphones to nearly maximum may cause music, etc. to sound distorted. If this occurs, lower the volume until the music sounds clear.

Remote control operation

Press the buttons on the headphones to operate the *Bluetooth* device remotely.

• Depending on the *Bluetooth* device, some functions may not operate even when the headphone buttons are pushed, or operate differently to the descriptions below.



Button	Operation	Action
	Press one time	Play/Pause
① Multifunction button	Press two times	Track forward
	Press three times	Track rewind
	+ short press	Increase the volume by one step
② Volume buttons	+ long press	Increase the volume continuously
E Volume buttons	- short press	Decrease the volume by one step
	- long press	Decrease the volume continuously


Note

The volume can be adjusted in 15 steps When the maximum or minimum level is reached an electronic tone sounds if a button is pressed.

Listening to music with the coil cable

If the device is not *Bluetooth* compatible, or if the battery level is low, you can use the supplied coil cable to use the headphones.

- ❖ To attach the cable
- 1 Hold the convex part of the cable plug at the angle shown in the diagram and insert the cable plug.




2 Rotate the convex part of the cable plug approximately 45 degrees clockwise to the position shown in the diagram to lock the cable plug.



❖ To detach the cable

1 Rotate the convex part of the cable plug approximately 45 degrees counterclockwise and then pull out the cable plug.



- Bluetooth does not turn on when the supplied cable is connected.
- The plug on the headphone end of the cable supplied with this product employs a structure
 to enable smooth insertion and removal, and secure locking in place to make
 disconnection during DJ performances difficult. This product is compatible with the cables
 supplied with the HDJ-X7, HDJ-X5, HDJ-X5BT and HDJ-CUE1 as they employ the same
 plug structure.
- If the supplied cable is connected while a *Bluetooth* connection is active, the *Bluetooth* function on the headphones turns off.

Call

If the *Bluetooth*-compatible telephone (cellular phone, smartphone, etc.) is compatible with "HSP" or "HFP" *Bluetooth* profiles, you can use these headphones to call.

- HSP (Headset Profile): You can receive monaural sound in the headphones and perform two-way communication with the microphone.
- HFP (Hands-Free Profile): Has communications transmission and receiving functionality in addition to HSP functions.
- Connect a *Bluetooth*-compatible telephone with the headphones. For information on how to connect, see "Connecting via *Bluetooth*" (page 5).

1 (Receiving an incoming telephone call) Press the multifunction button on the headphones once to receive a call.

(HFP only) To refuse a call, press and hold the multifunction button for at least two seconds.

(Placing a telephone call) Place a telephone call on a *Bluetooth*-compatible telephone.

- Read the user's manual of the *Bluetooth*-compatible telephone.
- To cancel the call, press the multifunction button once. The headphones emit an electronic tone. The headphones emit an electronic tone.

2 Call.

You can also adjust the volume while calling. For information on configuring settings, see "Remote control operation" (page 8).

3 Press the multifunction button on the headphones once to finish a call.

The headphones emit an electronic tone.

- These headphones are only compatible with receiving normal telephone calls. They are not compatible with smartphone or PC/Mac calling applications.
- Operation of hands-free settings, etc., on the *Bluetooth*-compatible telephone may be necessary.
- Depending on the *Bluetooth*-compatible telephone, the incoming and outgoing call sounds may be heard from the headphones.
- When using in locations where there are high levels of sound from the surrounding area,
 or in windy locations such as outdoors, conversations may be difficult to hear. In such
 cases, move to a different location or switch from using the headphones to using the
 Bluetooth-compatible telephone to call.
- The call function is not supported while the coil cable is connected.

Other fun	ctions			
Reset				

If you become unable to use the device, you can reset the headphones.

1 Press the multifunction button and "+" volume button simultaneously for at least five seconds while the power is on.

All previous operations will be reset. (Information on registered devices will also be deleted.) After resetting, power is turned off.

Status display LED

Blinks specific sequences and colors to provide notification of device status.

: Lit white

When the power is turned on* (lights for approximately one second)	
When not connected* (Blinks at about 2-second intervals)	0 0 0
When waiting for pairing*	
Connecting* (blinks slowly)	
Charging**	
Initialization (reset) complete (blinks for approximately two seconds)	0000

- * When the battery level of the device you are connecting becomes low, the color of the status display LED changes from white to red.
- ** When charging completes, the LED turns off.

Swivel rotation mechanism



This product is equipped with a swivel rotation mechanism that allows for various styles of monitoring. Before using the product, check its operation direction. Turning the headphones forcefully in an inappropriate direction may result in damage to the product.

Foldable construction

This product is designed to allow folding into a compact shape when not in use.



Troubleshooting

- As operation of Bluetooth devices differs according to the device, please read the user's manual of your Bluetooth device for more information.
- If the problem does not resolve, reset the headphones. For information on resetting, see "Reset" (page 13).
- If the headphones still do not operate normally after performing the procedures above, contact the service center or your dealer for repairs.

The power does not turn on.

· Charge the headphones.

Cannot charge the headphones.

- · Check that the PC/Mac is turned on.
- · Check that the PC/Mac is not set to power-saving mode.
- Check that the supplied USB charging cable is connected securely to the PC/Mac.

Cannot pair.

· Bring the headphones and the other device close together before pairing.

❖ Cannot establish a *Bluetooth* connection.

- · Check that the headphones and the other device are both turned on.
- Check if the *Bluetooth* function on the other device is turned on.

No sound is output (when playing back music).

- · Check that the headphones and the other device are both turned on.
- Check if the headphones and the paired device are connected via Bluetooth using A2DP.
- Check if the paired device is playing back music.
- Check if the playback volume is not set low on the paired device.

The sound is distorted (when playing back music).

 Check if there are any devices such as microwave ovens or wireless radios emitting electromagnetic waves in the 2.4 GHz frequency band, or if there are any obstacles in the area.

Troubleshooting

Cannot use hands-free operation.

- Check if the headphones and the paired device are connected via Bluetooth using HFP or HSP.
- If the paired device is connected via *Bluetooth* using A2DP, a switchover may be required, depending on the device specifications.

❖ Transmission distance is short, the sound skips.

• Check if there are any devices such as microwave ovens or wireless radios emitting electromagnetic waves in the 2.4 GHz frequency band, or if there are any obstacles in the area.

Specifications

General

PowerDC 5 V (when charging), DC 3.7 V (built-in rechargeable lithium polymer battery)		
Playback time *1	Approximately 30 hours	
Charging time *2 (25°C)	Approximately 2.5 hours	
Recommended charging temperature range	10°C to 35°C	
Usable temperature range	0°C to 40°C	
Usable humidity range	. 35% RH to 80% RH (with no condensation)	
Weight	250 g	

^{*1} Sometimes less depending on the conditions of use.

Bluetooth section

Version	Bluetooth standard version 5.0
Maximum transmission distance Appro	eximately 10 m * ³ in unobstructed circumstances
Frequency band used	2.4 GHz
Modulation method	FH-SS (Frequency hopping spread spectrum)
Compatible Bluetooth profiles	A2DP, AVRCP, HSP, HFP
Compatible codecs	SBC, AAC

^{*3} Transmission distances are a guideline. Transmission distance may change depending on the surrounding environment.

^{*2} Time required to fully charge from an empty state. Charging time may vary depending on the conditions of use.

Headphone section

Type	
Impedance	32 Ω
Sensitivity	104 dB
Frequency response	5 Hz to 30 000 Hz
Maximum input power	2 000 mW
Driver	ø40 mm
Plug	ø3.5 mm stereo mini-plug

Microphone section

Туре	Electric condenser
Directionality	Omni-directional
Active frequency band	100 Hz to 4 000 Hz

Other

Head cushion	Polyurethane (leather finish)
Ear pad	Polyurethane (leather finish)
Accessories	1.2 m Coiled cable (extended length 1.8 m) × 1,

USB charging cable (supplied) (0.5 m) \times 1,

Quick Start Guide × 1,

Precautions for use × 1

Note

Specications and design are subject to possible modications without notice due to improvements.

Trademarks and Registered Trademarks

- "Pioneer DJ" is a trademark of PIONEER CORPORATION, and is used under license.
- The names of companies and products mentioned herein are trademarks or registered trademarks of their respective owners.
- The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by AlphaTheta Corporation is under license. Other trademarks and trade names are those of their respective owners.

© 2020 AlphaTheta Corporation. All rights reserved. <DRC1421-B>